

SMART HOME MONITORING



# Smart Door Lock

Weiser SmartCode 10 Touchpad Electronic Deadbolt

Set-Up Guide

# Thanks for choosing Rogers Smart Home Monitoring!

Once you've set-up your Smart Door Lock, the lock will allow keyless entry without sacrificing any safety. Its Touchpad makes this an ideal deadbolt for any homeowner looking to add extra security without extra trouble. With Rogers Smart Home Monitoring you will have remote access to your Smart Door Lock and have peace of mind knowing your home is locked and secure wherever you are.

**Let's begin!**

# Helpful hints

Please refer to the enclosed **manufacturer's installation guide** for operating and safety instructions. To avoid injury, read all set-up and safety information included in your package before installing and setting up your Smart Door Lock. As set out in your service agreement, Rogers will not be liable for any damage to your property as a result of your installation. If you encounter a problem setting up your Smart Door Lock, or wish to book a Rogers technician to come set it up, please call Rogers Technical Support at **1 888 764-3771** or visit [www.rogers.com/install](http://www.rogers.com/install).

# Package contents

1. Smart Door Lock (Weiser Smartcode 10 Touchpad Electronic Deadbolt)
2. Manufacturer's installation guide

# Important installation steps

1. Remove the existing door lock.
2. Install the Smart Door Lock using the manufacturer's installation guide provided in the box.
3. Pair the Smart Door Lock to your Rogers Smart Home Monitoring system using this guide.

# Pairing the Smart Door Lock with your Touchpad


## Before you begin:

Once the Smart Door Lock has been physically installed and tested for proper functioning, follow the steps below to pair your Smart Door Lock with your Rogers Smart Home Monitoring system.


Note: Please install one Smart Door Lock at a time.



1. Ensure your system is disarmed.
2. On the Touchpad, select the **Settings** app from the Home Screen.




3. Enter your **4-digit** Master Access Code. (The same code that you use to manage your system.)




4. Select **Home Devices** under the **Categories** list.




5. Scroll down and select **Door Locks**, then select **Add a Door Lock**.




6. On the **Door Lock Devices Located** screen press **Next**. The system will take up to 30 seconds to find the Smart Door Lock.



7. Remove the Smart Door Lock's battery cover.




8. With the Smart Door Lock's battery cover removed and back plate exposed, press the **A** button 4 times until a red and amber indicator appears.



9. On the Touchpad a Pairing icon will appear and change to a Door Lock icon once pairing is complete. Please note this may take 2 to 5 minutes.

10. Click **Done** once the Door Lock icon appears and hit **Next** to confirm.



11. The Door Lock icon will appear again. Tap on the Door Lock icon to customize its name (e.g. Front Door).

12. Click **Return to Menu** to complete the pairing of the Smart Door Lock.

# Your installation is done!

Your Smart Door Lock is now part of your Smart Home Monitoring system. Now you can control the Smart Door Lock remotely with your Touchpad, your smartphone app and through the Web Control Centre.


## Start using this device:

Use your smartphone app or visit the Web Control Centre at [smarthome.rogers.com](http://smarthome.rogers.com) to:

- Set up rules to receive a text message or email when you lock or unlock your Smart Door Lock.
- Remotely lock and unlock your home.
- Learn more about the features of your Smart Home Monitoring system.

## How to reset this device:

If you are trying to add your Smart Door Lock to your system and are unable to pair it in the first few attempts, or if you see an error while pairing, try the following steps to reset the Smart Door Lock and then pair again.



1. Remove battery pack.
2. Press and hold the **Program** button while reinserting the battery pack. Hold the **Program** button for 30 seconds until the status LED flashes red.
3. Press the **Program** button again. The Smart Door Lock has been reset when the LED flashes green.
4. Verify the Smart Door Lock has been reset by pressing the **Lock** button while the door is open. If the bolt does not extend to lock the door lock, it has been successfully reset.

**Note:** Door lock handing procedure must be completed after lock has been reset.




## How to remove this device from your system:


Should you need at any point in the future to remove the Smart Door Lock from your Rogers Smart Home Monitoring system, follow the steps below:




1. Ensure your Smart Home Monitoring system is disarmed.
2. On the Touchpad, select the **Settings** app from the **Home Screen**.



3. Enter your **4-digit** Master Access Code (This is the same code that you use to manage your system.)



4. Select **Home Devices** under the **Categories** list.



5. Under **Home Devices**, select **Door Locks**. On the next screen, select **Delete Door Locks**.
6. Now, select the Smart Door Lock you want to delete and press **Yes** to confirm.

The Smart Door Lock you selected has now been removed from your system.

7. Click **Return to Menu** to exit the screen.